

Cable-Shift
Cable Length Measurement
Subaru

Measure cable lengths from center of shifter handle position to dimple in transaxle shift rod. Measurement is taken along the running length.

The best way to measure is to:

1. Have a helper hold the body of the tape measure at the nose cone end of the transaxle.
2. Feed the tape over the left side CV joint (as viewed from the rear) and along the left side of the engine sump.
3. Proceed with the end of tape (over or under the fuel tank if necessary) to a point between and ahead of the seats where the centerline of the shift handle will be.
4. Read the tape (in whole inches) at the thru hole in the transaxle shift rod.

Note: This measurement will determine both cable lengths.